

JetMPrints™ Opaque

One Step Opaque Transfer Paper

JetMPrints™ Opaque Instructions - For Hand Ironing

You will need the following items:

1. A pre-washed and dried color t-shirt
2. A hand iron (emptied of all water and pre-heated for at least 8 minutes on the cotton setting)
3. A hard flat surface - like a counter top. Do not use on glass or metal surface. An ironing board is not recommended.

Image the Jet Opaque in your inkjet printer on the side without the line. **DO NOT REVERSE OR FLIP IMAGE**. Select a printer setting that will not use extremely high levels of ink (i.e. plain paper). After the image is printed be sure it is completely dry.

Lay the t-shirt on the work surface and preheat it with the iron to remove excess moisture and remove the wrinkles. Allow the fabric to cool completely.

Trim the image if necessary. Carefully remove and discard the paper backer (the side with the line) from the Jet Opaque. Put the image face up on the t-shirt. Lay the lightweight ironing sheet over the surface of the transfer. Use medium/firm pressure, slide the iron up and down, keep iron moving constantly. Make sure to cover the edges of the image completely. For full size sheet, iron 2-3 minutes. For 1/2 sheet, iron 1-1 1/2 minutes. Allow the shirt to cool completely and remove the ironing sheet.

Laundry Instructions

Turn the garment inside-out before laundering. Wash in warm water using a gentle detergent. AVOID BLEACH OR BLEACH ALTERNATIVE DETERGENTS. Tumble dry on low or medium setting with shirt turned inside-out.

JetMPrints™ Opaque Instructions - For Heat Press Application

Preheat the heat press to 325° F. Image the Jet Opaque in your inkjet printer on the side without the line. **DO NOT REVERSE OR FLIP IMAGE**. After the image is printed be sure it is completely dry.

Preheat the t-shirt on the press to remove excess moisture and wrinkles. Trim the image if necessary. Carefully remove and discard the paper backer (the side with the line) from the Jet Opaque. Put the image face up on the t-shirt. Lay the lightweight ironing sheet over the surface of the transfer. Press at 325° F for 15 seconds using medium pressure. Allow the shirt to cool completely and remove the ironing sheet.

Laundry Instructions

Turn the garment inside-out before laundering. Wash in warm water using a gentle detergent. AVOID BLEACH OR BLEACH ALTERNATIVE DETERGENTS. Tumble dry on low or medium setting with shirt turned inside-out.