



Step 1. ImageClip Transfer Paper comes with two separate sheets. The sheet with the **red writing** is the **transfer sheet**, which will run through your color laser copier or color laser printer. The **green sheet** is the **weeding sheet**, which removes any unprinted emulsion layer from the transfer sheet.



Step 2. Separate the **red transfer sheets** from the **green weeding sheets**. Remember, the red transfer sheets feeds through your color laser printer or color laser copier. **DO NOT USE** green sheets in your printer.



Step 3. Load the **red transfer sheet** into the Manual Paper Tray of your Color Laser. Consult your user’s guide to your color laser for loading the “print side” of the paper in your Manual Paper Tray. Set the media weight of your printer or copier for “Heavy” or “Thick Stock” mode. Consult your user’s guide to your color laser for setting the media weight.



Step 4. Print your image to the blank side of the red transfer sheet. Make sure to “mirror” or “reverse” your image.



Step 5. To weed the **red transfer sheet**, set your heat press for 210° F, set your pressure to Light (20-25 psi), and set your timer for 10 seconds.



Step 6. Place a Teflon Sheet or other protective sheet over the bottom platen of your heat press. Place the **red transfer sheet** on the press with the image side up.



Step 7. Place the **green weeding sheet** over the image on the **red transfer sheet**. The writing on the green weeding sheet should be facing you.



Step 8. Drop platen of heat press, and press **red transfer sheet** and **green weeding sheet** together at 210° F for 10 seconds with a light pressure. When timer sounds, open the heat press.



Step 9. Immediately peel **green weeding sheet** away from **red transfer sheet** using a steady motion.



NOTE!: Your image will have a “haze” after the weeding step.



Step 10. To transfer the **red transfer sheet** to your fabric or garment, reset your heat press for 400° F, set your pressure to Heavy (60-80 psi), and set your timer for 15 seconds.



Step 11. Place your white or light-colored fabric or garment onto your heat press, and “pre-press” for 5-10 seconds. This will evaporate any moisture built up in the fabric.



Step 12. Take the **red transfer sheet** (weeded) and position over your fabric or garment.



Step 13. Drop platen of heat press, and press **red transfer sheet** to your fabric or garment at 400° F for 15 seconds with a Heavy (60-80psi) pressure. When timer sounds, open the heat press.



Step 14. Immediately peel **red transfer sheet** away from your fabric or garment using a steady motion.



Your digital image is now on your fabric, without a paper outline appearing on your fabric or garment!

Condé Systems, Inc. provides products that are intended for professional use only and for users who have read and understood the instructions for proper application. Please consult a qualified Condé technician for inquiries where further clarification is required. Improper use and installation will result in undesirable results in the imprinted item and damage to your heat press, printer components and other related equipment. Condé Systems, Inc. assumes no liability whatsoever, expressed or implied, for the use of these products, nor their installation. Condé Systems assumes no legal liability or responsibility for the accuracy, completeness or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately-owned rights. Past performance is not necessarily indicative of future results.

All instructions and product specifications are subject to change without notice. Please visit our web site at www.conde.com for pertinent updates.